

WARNING

The power light turns red to indicate low battery power and turns off when the battery level is less than 10 %. Remember to charge the device on time to avoid any problem.

Store the wireless microphone in a dry and ventilated place to avoid humidity.

Do not open the device yourself. For any service or repair please contact your local distributor or a qualified specialist.

We reserve the right to update specifications and instructions without further notice.

Stagg®



EMD Music - 07/2019

Stagg®

USER MANUAL



SUW 12H-BE

BEIGE WIRELESS HEADSET MICROPHONE SET

Please read the instructions carefully before use



PRODUCT FEATURES

Wireless 2.4 GHz headset condenser microphone transmitter and receiver

Couple automatically, easy to operate

Up to 4 identical systems can work together

Both transmitter and receiver work on rechargeable lithium battery

Work together with battery-powered speakers for a versatile solution

Up to 6 hours using time

Suitable for many different situations, such as presentations, educational events and singing performances. Could be used as a computer microphone and for video sound recording

TECHNICAL PARAMETERS

Frequency range: 2.4 GHz

Frequency response: 20 Hz - 20 KHz (+/- 3 dB)

Output impedance: ≤ 2200 ohms

Pairing method: Automatic

Microphone type: Condenser

Microphone directivity: Unidirectional

Microphone diameter: 6 x 2.7 mm (0.2 x 0.1")

Microphone sensitivity: - 45 dB (+/- 2dB)

Signal to noise ration: > 63 dB

Power supply: Rechargeable lithium battery

Power consumption: < 70 mA at 0 dBm

Operating voltage: 2.0 – 10 V DC

Operational distance: 25 metres (82 feet)

Operational time: Up to 6 hours

PACKAGE CONTENT

Transmitter	1
Receiver	1
Beige headset with boom microphone	1
6.35 mm audio adapter plug	1
Double charger cord	1
User manual	1

INSTRUCTIONS

1. Connect the receiver to the MIC input of an amplifier, speaker or other audio equipment. Use the 6.35 mm audio adapter plug if needed.
2. Turn on the receiver using the power switch. The power light will blink.



3. Turn on the transmitter using the power switch. The power light will blink. The transmitter and receiver will match automatically. Once matched, the power lights stay on.



4. Adjust the volume to the desired level thanks to the volume buttons.



5. Place the microphone. The system is ready to use.